


4 - GEAR ASSEMBLY



SR NO	DESCRIPTION	QTY
1	CHUTCH BEARING KIT	1
2	OIL SEAL KIT FOR GEARBOX	1
3	GEARBOX HOUSING	1
4	FASTENER KIT FOR GEARBOX	1
5	CLUTCH FOR LINKAGE KIT	1
6	SHIFTER FORK KIT FOR GEAR BOX	1
7	GEAR LEVER LINKAGE KIT	1
8	SHAFT FOR REVERSE GEAR	1
9	REVERSE GEAR	1
10	BEARING SET FOR GEAR BOX	1
11	SHAFT INPUT GEAR (12,13,14,15,16)	1
12	4TH DRIVE GEAR	
13	3RD DRIVE GEAR	
14	2ND DRIVE GEAR	
15	REVERSE DRIVE GEAR	
16	1ST DRIVE GEAR	
17	1ST DRIVEN GEAR	1
18	REVERSE DRIVEN GEAR	1
19	2ND DRIVEN GEAR	1
20	3RD DRIVEN GEAR	1
21	4TH DRIVEN GEAR	1
22	MAIN SHAFT WITH REDUCTION GEAR	1
23	REDUCTION DRIVEN GEAR	1
24	GEAR HOUSINGFOR REDUCTION GEAR	1
25	BEARING SET FOR RED GEAR HOUSING	1
26	SHIFTER HUB KIT GOR GEARBOX	1
27	SYN RING SET FOR GEARBOX	1